

DekDrain Eezee

Installation Instructions



1. Mark lay out of the linear drainage with a line.
2. Dig a trench, measuring the depth of the channel plus the measurement of Z (see below illustration).
 - 2a. example - 98mm (depth of channel) + 150mm (Z for B125) = 248mm trench depth.
3. Make a concrete bedding with a minimum height of Z measurement. Wait 60 minutes until the concrete is the right consistency.
4. Prepare all components for assembling.
5. Connect drain channels, put end caps and outlet on. Join outlet with sewage pipe. Check the channel alignment. Before the concrete bedding is dry, lay channels with grates fitted on the concrete bed and level them. It is recommended that the channels position should be 2-5mm below the surface level. This guarantees optimal water collection.
6. After binding the concrete bedding, carefully fill the rest of the trench with concrete. Pour concrete the measurement of X to either side of the drainage.

